




保存版

# Motorcycle Owner's Manual

KX125  
KX250  
KX500



Whenever you see the symbols shown below, heed their instructions! Always follow safe operating and maintenance practices.

### **⚠ WARNING**

This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life.

### **CAUTION**

This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

### **NOTE**

○ *This note symbol indicates points of particular interest for more efficient and convenient operation.*

### **⚠ WARNING**

**THIS VEHICLE IS A COMPETITION MODEL ONLY AND WAS NOT MANUFACTURED FOR, NOR SHOULD IT BE USED ON, PUBLIC STREETS, ROADS, OR HIGHWAYS. THE USE OF THIS VEHICLE SHOULD BE LIMITED TO PARTICIPATION IN SANCTIONED COMPETITION EVENTS UPON A CLOSED COURSE. THIS VEHICLE SHOULD NOT BE USED FOR GENERAL OFF-ROAD RECREATIONAL RIDING.**

### **DISCLAIMER OF WARRANTY**

**THIS MOTORCYCLE IS SOLD AS IS, WITH ALL FAULTS, OBVIOUS OR CONCEALED AND THERE ARE NO WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OF FITNESS.**

The purchaser accepts all responsibilities concerning quality, performance, cost of service and/or necessary repairs.

### **IMPORTANT**

Off-road motorcycle riding is a wonderful sport, and we hope you will enjoy it to the fullest.

However, if improperly conducted, the sport has the potential to cause environmental problems as well as conflicts with other people. Responsible use of your off-road motorcycle will ensure that these problems and conflicts do not occur.

**TO PROTECT THE FUTURE OF YOUR SPORT, MAKE SURE YOU USE YOUR BIKE LEGALLY, SHOW CONCERN FOR THE ENVIRONMENT, AND RESPECT THE RIGHTS OF OTHER PEOPLE.**

# Foreword

Congratulations for choosing this KAWASAKI Motorcycle, which has been developed through Kawasaki engineering to produce a light weight, high performance machine with superb handling and stability for racing and sporting use.

Your new KX is a highly tuned production racer for participation in racing events. As with any mechanical device, proper care and maintenance are important for trouble-free operation and top performance. This guide is written to enable you to keep your KX properly tuned and adjusted.

Due to improvements in design and performance during production, in some cases there may be minor discrepancies between the actual vehicle and the illustrations and text in this manual.





Driving system		Chain drive
Gear ratio:	1st	2.384 (31/13)
	2nd	1.857 (26/14)
	3rd	1.529 (26/17)
	4th	1.294 (22/17)
	5th	1.125 (27/24)
	6th	1.000 (25/25)
Primary reduction ratio		3.200 (64/20)
Final reduction ratio		4.000 (48/12)
Overall drive ratio		12.800 (Top gear)
Transmission oil:	Capacity	700 mL (0.74 US qt)
	Type	SE, SF or SG class SAE 10W-30 or 10W-40
<b>Frame</b>		
Type		Tubular, semi-double cradle
Steering angle		45° to either side
Castor		26°
Trail		109 mm (4.29 in.)
Tire size:	Front	80/100-21 51M, DUNLOP K490
	Rear	100/90-19 57M, DUNLOP D737
Suspension:	Front	Telescopic fork (upside-down)
	Rear	Swingarm (Uni-trak)
Front suspension stroke		310 mm (12.20 in.)
Rear wheel travel		330 mm (12.99 in.)
Front fork oil (each)		KAYABA 01 or SAE 5W20, 615 – 623 mL (20.79 – 21.06 US oz)
Front fork oil level (compressed, spring removed)		90 mm (3.54 in.)
<b>Brakes</b>		
Type:	Front and Rear	Disc brake
Effective disc diameter:	Front	220 mm (8.66 in.)
	Rear	190 mm (7.48 in.)

Specifications subject to change without notice, and may not apply to every country.

**KX250:****Dimensions**

Overall length	2,175 mm (85.63 in)
Overall width	815 mm (32.09 in.)
Overall height	1,210 mm (47.64 in.)
Wheelbase	1,480 mm (58.27 in.)
Road clearance	380 mm (14.96 in.)
Dry weight	97 kg (214 lb)
Fuel tank capacity	8.5 L (2.25 US gal)

**Engine**

Type	2-stroke, single cylinder, piston reed valve, liquid-cooled "This engine licensed under one or more of Eyvind Boyesen's Patent Nos: 3 905 340. 3 905 341. Re. 30 425. 4 062 331; 4 161 163. 4 202 298 and 4 202 299."	
Bore and stroke	66.4 x 72.0 mm (2.61 x 2.85 in.)	
Displacement	249 mL (15.25 cu in.)	
Compression ratio:	Low speed 10.8 : 1 High speed 9.0 : 1	
Port timing:	Intake	Open Close
	Scavenging	Open Close
	Exhaust	Open Close
Carburetor	KEIHIN PWK38	
Lubrication system	Petrol mix (32 : 1)	
Starting system	Primary kick	
Ignition system	CDI system	
Ignition timing	11.0° BTDC @7,000 r/min (rpm)	
Spark plug (Terminal)	NGK BR8EVX (Solid post)	

**Transmission**

Transmission type	5-speed, constant mesh, return shift	
Clutch type	Wet, multi disc	
Driving system	Chain drive	
Gear ratio:	1st	2.133 (32/15)
	2nd	1.625 (26/16)
	3rd	1.333 (24/18)



	4th	1.136 (25/22)
	5th	1.000 (24/24)
Primary reduction ratio		2.750 (55/20)
Final reduction ratio		3.692 (48/13)
Overall drive ratio		10.153 (Top gear)
Transmission oil:	Capacity	850 mL (0.90 US qt)
	Type	SE, SF or SG class SAE 10W-30 or 10W-40
<b>Frame</b>		
Type		Tubular, semi-double cradle
Steering angle		45° to either side
Castor		26°
Trail		109 mm (4.29 in.)
Tire size:	Front	80/100-21 51M, BRIDGESTONE M77
	Rear	110/90-19 62M, BRIDGESTONE M78A
Suspension:	Front	Telescopic fork (upside-down)
	Rear	Swingarm (Uni-trak)
Front suspension stroke		310 mm (12.20 in.)
Rear wheel travel		330 mm (12.99 in.)
Front fork oil (each)		KAYABA 01 or SAE 5W20, 615 ~ 623 mL (20.79 – 21.06 US oz)
Front fork oil level (compressed, spring removed)		90 mm (3.54 in.)
<b>Brakes</b>		
Type:	Front and Rear	Disc brake
Effective disc diameter:	Front	220 mm (8.66 in.)
	Rear	190mm (7.48 in.)

Specifications subject to change without notice, and may not apply to every country.

**KX500:****Dimensions**

Overall length	2,190 mm (86.22 in)
Overall width	815 mm (32.09 in.)
Overall height	1,205mm (47.44 in.)
Wheelbase	1,490 mm (58.66 in.)
Road clearance	370 mm (14.57 in.)
Dry weight	100 kg (220 lb)
Fuel tank capacity	9.9 L (2.62 US gal)

**Engine**

Type	2-stroke, single cylinder, piston reed valve, liquid-cooled "This engine licensed under one or more of Eyvind Boyesen's Patent Nos: 3 905 340. 3 905 341.Re. 30 425. 4 0.62 331; 4 161 163. 4 202 298 and 4 202 299."	
Bore and stroke	86.0 x 86.0 mm (3.39 x 3.39 in.)	
Displacement	499 mL (30.45 cu in.)	
Compression ratio:	Low speed 8.4 : 1 High speed 7.4 : 1	
Port timing:	Intake	Open Close Full open
	Scavenging	Open Close 60° BBDC 60° ABDC
	Exhaust	Open Close (Low speed) 83.5° BBDC, (High speed) 93.5° BBDC (Low speed) 83.5° ABDC, (High speed) 93.5° ABDC
Carburetor	KEIHIN PWK39	
Lubrication system	Petrol mix (32 : 1)	
Starting system	Primary kick	
Ignition system	CDI system	
Ignition timing	19° BTDC @6000 r/min (rpm)	
Spark plug (Terminal)	NGK BR8EG (Solid post)	

**Transmission**


Transmission type	5-speed, constant mesh, return shift	
Clutch type	Wet, multi disc	
Driving system	Chain drive	
Gear ratio:	1st	2.000 (32/16)
	2nd	1.444 (26/18)
	3rd	1.181 (26/22)

	4th	0.954 (21/22)
	5th	0.791 (19/24)
Primary reduction ratio		2.538 (66/26)
Final reduction ratio		3.357 (47/14)
Overall drive ratio		6.746 (Top gear)
Transmission oil:	Capacity	800 mL (0.85 US. qt)
	Type	SE, SF or SG class SAE 10W-30 or 10W-40
<b>Frame</b>		
Type		Tubular, semi-double cradle
Steering angle		45° to either side
Castor		27°
Trail		116 mm (4.57 in.)
Tire size:	Front	80/100-21 51M, DUNLOP K490
	Rear	120/90-19 66M, DUNLOP K695
Suspension:	Front	Telescopic fork (upside-down)
	Rear	Swingarm (Uni-trak)
Front suspension stroke		310 mm (12.20 in.)
Rear wheel travel		330 mm (12.99 in.)
Front fork oil (each)		KAYABA 01 or SAE 5W20, 604 ~ 612 mL (20.42 ~ 20.69 US oz)
Front fork oil level (compressed, spring removed)		90 mm (3.54 in.)
<b>Brakes</b>		
Type:	Front and Rear	Disc brake
Effective disc diameter:	Front	220 mm (8.66 in.)
	Rear	190mm (7.48 in.)


Specifications subject to change without notice, and may not apply to every country.




**KX125:**



**KX500:**




**KX250:**




- 7. Front Fork
- 8. Radiator
- 9. Fuel Tank
- 10. Fuel Tap
- 11. Carburetor
- 12. Air Cleaner Rotary Shutter (KX500 only)
- 13. Seat
- 14. Brake Disc
- 15. Brake Caliper
- 16. Shift Pedal
- 17. Rear Shock Absorber
- 18. Swingarm
- 19. Drive Chain
- 20. Chain Guide


### KX125:



### KX500:




### KX250:



- 21. Silencer
- 22. Gas Reservoir
- 23. Rear Brake Reservoir
- 24. Uni-trak Tie Rod and Rocker Arm
- 25. Kick Pedal
- 26. Rear Brake Pedal
- 27. Transmission Oil Level Gauge
- 28. Muffler

## Side Stand

Position the side stand through the gusset portion at the left side of the frame pipe with the longer bar facing inside and parallel with the connection frame pipe.



A. Side Stand  
B. Longer Bar

C. Connection Frame Pipe

### NOTE

○ Do not start the engine or ride the motorcycle when the side stand is used.

## Air Cleaner Rotary Shutter (KX500 only)

A rotary shutter is equipped to the left and right sides of the air cleaner case respectively.

When the shutter is opened, extra air is led to the air cleaner case, so more efficient intake is obtained.

### NOTE

○ The rotary shutter should be closed in the wet condition to prevent rain from entering.




A. Rotary Shutter

## Fuel

The Kawasaki KX has a 2-stroke engine that requires a gasoline-oil mixture.

Fuel Tank Capacity	
KX125, 250	8.5 L (2.25 US gal)
KX500	9.9 L (2.62 US gal)

To open the fuel tank cap, pull out the breather hose from the hole of the steering shaft, and turn the tank cap counterclockwise.



A. Fuel Tank Cap

B. Breather Hose

## ⚠ WARNING

Gasoline is extremely flammable and can be explosive under certain conditions. Always stop the engine and do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

## Fuel Requirements:

### *Fuel Type*

Use clean, fresh unleaded gasoline with a minimum Antiknock Index of 90. The Antiknock Index is posted on service station pumps in the U.S.A. The octane rating of a gasoline is a measure of its resistance to detonation or "knocking." The Antiknock Index is an average of the Research Octane Number (RON) and the Motor Octane Number (MON) as shown in the table below.

Octane Rating Method	Minimum Rating
Antiknock Index $\frac{(\text{RON} + \text{MON})}{2}$	90
Research Octane Number (RON)	95



### CAUTION

If engine "knocking" or "pinging" occurs, use a different brand of gasoline of a higher octane rating. If this condition is allowed to continue it can lead to severe engine damage.

Gasoline quality is important. Fuels of low quality or not meeting standard industry specifications may result in unsatisfactory performance. Operating problems that result from the use of poor quality or nonrecommended fuel may not be covered under your warranty.

#### *Fuels Containing Oxygenates*

Gasoline frequently contains oxygenates (alcohols and ethers) especially in areas of the U.S. and Canada which are required to sell such reformulated fuels as part of a strategy to reduce exhaust emissions.

The types and volume of fuel oxygenates approved for use in unleaded gasoline by the U.S. Environmental Protection Agency include a broad range of alcohols and ethers, but only two components have seen any significant level of commercial use.

Gasoline/Alcohol Blends – Gasoline containing up to 10% ethanol (alcohol produced from agricultural products such as corn), also known as "gasohol" is approved for use.

### CAUTION

Avoid using blends of unleaded gasoline and methanol (wood alcohol) whenever possible, and never use "gasohol" containing more than 5% methanol. Fuel system damage and performance problems may result.

Gasoline/Ether Blends – The most common ether is methyl tertiary butyl ether (MTBE). You may use gasoline containing up to 15% MTBE.

### NOTE

○ *Other oxygenates approved for use in unleaded gasoline include TAME (up to 16.7%) and ETBE (up to 17.2%). Fuel containing these oxygenates can also be used in your Kawasaki.*

## CAUTION

Never use gasoline with an octane rating lower than the minimum specified by Kawasaki.

Never use "gasohol" with more than 10% ethanol, or more than 5% methanol. Gasoline containing methanol must also be blended with cosolvents and corrosion inhibitors.

Certain ingredients of gasoline may cause paint fading or damage. Be extra careful not to spill gasoline or gasoline oxygenate blends during refueling.

When not operating your Kawasaki for 30 to 60 days, mix a fuel stabilizer (such as STA-BIL) with the gasoline in the fuel tank. Fuel stabilizer additives inhibit oxydation of the fuel which minimizes gummy deposits.

Never store this product with "gasohol" in the fuel system. Before storage it is recommended that you drain all fuel from the fuel tank and carburetors. See the Storage section in this manual.

### Engine Oil Mixing

Oil must be mixed with the gasoline to lubricate the piston, cylinder, crankshaft, bearings, and connecting rod bearings.

#### Recommended Oil:

- Kawasaki 2-stroke racing oil
- Shell Super-M
- Castrol A747
- Castrol TTS (A545)
- Castrol Pure racing for 2-stroke Motorcycles
- Rock Oil K2

## NOTE

- If none of the recommended oils are available, use 2-stroke racing oil only.

### Gasoline and engine oil mixing ratio:

**32 : 1 (Gasoline 32, Engine Oil 1)**

(A 32 to 1 mixture is 4 fluid ounces of oil per gallon of gasoline or about 31 mL of oil per liter of gasoline.)

## CAUTION

Do not mix vegetable and mineral based oils. Too much oil will cause excessive smoking and spark plug fouling. Too little oil will cause engine damage or premature wear.

To make an gasoline-oil mixture, pour oil and half of the gasoline into a container first and stir the mixture thoroughly. Then add the rest of the gasoline and stir the mixture well.


## NOTE

- At low temperature, oil will not easily mix with gasoline. Take time to ensure a well-blended mixture.
- The lubricative quality of this mixture deteriorates rapidly; use a fresh mixture for each day of operation.

## Starting the Engine


- Turn the fuel tap to the ON position.

KX125, 250:




A. Fuel Tap  
B. OFF position

KX500:




C. ON position

- If the engine is cold, pull up the choke knob.



A. Choke Knob

- Kick the engine over, leaving the throttle closed.



**A. Kick Pedal**

- Even after the engine starts, keep the choke knob pulled up. When the engine is thoroughly warmed up, push down the choke knob.

#### **NOTE**

- *When the engine is already warm or on hot days, open the throttle part way instead of using the choke knob.*
- *If the engine is flooded, kick with the throttle fully open until the engine starts.*
- *If the clutch lever is pulled, the motorcycle can be started while in any gear.*

## **Shifting Gears**

The transmission is a 5-speed (KX125: 6-speed), return shift type with neutral halfway between 1st and 2nd gears. A "return shift" means that to go back to first gear from a higher gear, you must shift back through the gears one by one. The same is true when upshifting: each gear must be engaged before the next higher gear may be selected.


To engage first gear from neutral, pull in the clutch lever and push down on the shift pedal, gently release the clutch lever, then release the shift pedal.

To shift to the next higher gear; pull in the clutch lever, lift the shift pedal with your toe, gently release the clutch lever, and then release the shift pedal.

To shift to the next lower gear; disengage the clutch, push the shift pedal down as far as it will go, engage the clutch gently, and then release the shift pedal.

### **CAUTION**

**When changing gears, press firmly on the shift pedal to ensure complete, positive shifting. Careless, incomplete shifts can cause the transmission to jump out of gear and lead to engine damage.**




A. Shift Pedal

## Stopping the Motorcycle

For maximum deceleration, close the throttle and apply both front and rear brakes. Disengage the clutch as the motorcycle comes to a stop. Independent use of the front or rear brake may be advantageous under certain conditions. Downshift progressively as speed is reduced to ensure good engine response when you want to accelerate.

## Stopping the Engine

- Shift the transmission into neutral.
- After racing the engine slightly, close the throttle completely and push the engine stop button.



A. Engine Stop Button

- Turn the fuel tap to the OFF (stop) position.

## Break-In

To obtain the proper operating clearance in the engine and transmission that are necessary for smooth engine performance and reliability, a brief break-in procedure must be carried out. For the first hour or 20 km (12 mi) of operation, run the engine at low and moderate r/min (rpm).

### NOTE

○ *The slow riding necessary during the break-in period may cause carbon to build up on the spark plug and foul it. If inspection of the spark plug shows this to be the case, replace the standard spark plug with a hotter spark plug for the duration of the break-in period.*

Spark Plug		
	Standard Plug	Hotter Plug
KX125	NGK BR9EVX	NGK BR8EVX
KX250	NGK BR8EVX	NGK BR7EVX
KX500	NGK BR8EG	NGK BR7EG

Break-in according to the following steps.

1. Start the engine and let it run at idle until the engine is thoroughly warmed up.
2. Stop and let the engine cool completely.
3. Start the engine and ride for 10 minutes at moderate speed – **NEVER HARD ACCELERATION.**
4. Stop and let the engine cool completely. Be sure to check and adjust chain slack and spoke tightness and make a general inspection.
5. Start the engine and ride for 20 minutes at moderate speed – **NEVER HARD ACCELERATION.**
6. Stop and let the engine cool completely. Check and adjust as step 4. Then drain the coolant, remove the cylinder head, cylinder and piston, and inspect these parts.

Piston: A piston scored at the piston skirt could lower engine performance or damage the cylinder wall. Such scores, if any, must be smoothed with #400 to #600 emery cloth.

Cylinder: Decarbon the exhaust ports and the upper part of the cylinder, taking care not to damage the cylinder wall. Scores on the cylinder wall should be smoothed with #400 to #600 emery cloth.

Cylinder Head: Remove the carbon inside the combustion chamber.

7. Install the parts removed.

8. Fill the radiator up to the bottom of the radiator filler neck with coolant. Before putting the motorcycle into operation, bleed the air from the cooling system.
9. Start the engine and ride for **30** minutes at moderate speed – **NEVER HARD ACCELERATION**.
10. Stop and let the engine cool completely. Check and adjust as Step 4.
11. After the brake-in procedure has been properly carried out, the motorcycle is ready for regular operation. However, since recklessly high r/min (rpm) will lead to engine trouble, take care to use the necessary skill and technique in operating the motorcycle.

### NOTE

○ *After break-in, install a new standard spark plug, and change the transmission oil.*

#### For your reference:

To keep optimum engine performance, replace the piston rings with new ones after break-in.

## Daily Pre-ride Inspection

Check the following items each day before you ride. The time required is minimal, and habitual performance of these checks will help ensure you a safe, reliable ride.

If any irregularities are found during these checks, refer to the appropriate owner's manual section and take the action required to return the motorcycle to a safe operating condition.

### WARNING

**Failure to perform these checks every day before you ride may result in serious damage or severe accident.**

#### Engine

Transmission oil .....	No transmission oil leakage, transmission oil level correct.
Coolant.....	No coolant leakage, coolant level correct (when engine is cold).
Radiator cap .....	Properly installed.
Spark plug .....	Tighten to correct torque.
Cylinder head .....	Tighten to correct torque.
Cylinder .....	Tighten to correct torque.
Clutch .....	Clutch functioning properly.
Carburetor .....	Adjusted properly.
Air cleaner .....	Clean, properly installed.
Muffler.....	Muffler not damaged.
Engine sprocket.....	Not worn or damaged.

## Frame

Tires .....	Check overall condition; wear, cuts and other damage. Check pressure.
Spokes.....	Check for any loose spokes.
Drive chain .....	Check overall condition and chain slack, oil as necessary.
Brakes; front and rear.....	Function properly, brake lever and pedal have correct play. No brake fluid leakage.
Throttle .....	Functions properly, returns smoothly.
Steering .....	Action is smooth but not loose from lock to lock. No binding of control cables.
Front fork.....	Functions properly, no oil leakage.
Rear shock absorber .....	Function properly, no oil leakage.
Fuel tank.....	Mounted securely, no fuel leakage.
Rear sprocket .....	Not worn or damaged.
Engine stop button .....	Functions properly.
Nuts, bolts, fasteners.....	Tighten any loose bolts and nuts.

## After Race Check Points

After racing, first clean the motorcycle (Pg. 84), then inspect the entire motorcycle with special attention to the air cleaner, carburetor, brakes, etc.

Carry out general lubrication (Pg. 85) and make adjustments as necessary.





OPERATION		FREQUENCY						See Page
		Each race	Every 3 races	Every 5 races	Every 10 races	As required		
CHASSIS	Brake fluid level--check †		●					57
	*Brake fluid--change			Every 2 years				—
	*Brake master cylinder cup and dust seal--replace			Every 2 years				—
	*Brake caliper piston seal and dust seal--replace			Every 2 years				—
	*Brake hose and pipe--replace			Every 4 years				—
	Spoke tightness and rim runout--check †	●						77,78
	Drive chain--adjust	●						48
	Drive chain--lubricate	●						51,87
	Drive chain wear--check †			●				49
	Chain slipper and guide--replace			Damaged				50
	Front fork--inspect/clean	●						61
	*Front fork oil--change			1st time after 2 races, then every 5 races				
	Nuts, bolts, fasteners--check †	●						80
	Fuel hose--replace			Every 4 years				—
	Fuel system--clean	●						—
	Steering play--check †	●						59
	*Steering stem bearing--grease			●				—
	Rear sprocket--check †			●				51
	General lubrication--perform	●						85
	*Wheel bearing--check †				●			—
*Swingarm and Uni-trak linkage pivots--check †			●				—	
*Swingarm and Uni-trak linkage pivots--grease			●				—	
*Rear shock oil--replace			1st time after 2 races, then every 5 races				—	

†: Replace, add, adjust or torque if necessary.

\*: Should be serviced by referring to the Service Manual or an authorized Kawasaki dealer.


R: Replace

## Transmission Oil

In order for the transmission and clutch to function properly, maintain the transmission oil at the proper level, and change the oil periodically. Motorcycle operation with insufficient, deteriorated, or contaminated transmission oil will cause accelerated wear and may result in transmission seizure.

### *Oil Level*

- Situate the motorcycle so that it is perpendicular to the ground.
- If the motorcycle has just been used, wait several minutes for all the oil to settle.
- Check the transmission oil level through the oil level gauge in the lower right side of the engine. The oil level should come up between the upper and lower level.



A. Oil Level Gauge

B. Upper Level

C. Lower Level


- ★ If the oil level is too high, remove the excess oil using a syringe or other suitable device.
- ★ If the oil level is low, add the correct amount of oil through the oil filler opening. Use the same type and brand of oil that is already in the engine.

### Transmission Oil

Grade:	SE, SF or SG class
Viscosity:	SAE 10W-30 or 10W-40 motor oil
Capacity:	KX125 : 700 mL (0.74 US qt)
	KX250 : 850 mL (0.90 US qt)
	KX500 : 800 mL (0.85 US qt)



A. Oil Filler Opening



A. Drain Plug

### Oil Change

The transmission oil should be changed periodically to ensure long engine life.

- Warm up engine thoroughly so that the oil will pick up any sediment and drain easily.
- Stop the engine, and place an oil pan beneath the engine.
- Remove the drain plug and position the vehicle so that it is perpendicular to the ground to allow all the oil to drain out.

### **▲WARNING**

**Motor oil is a toxic substance. Dispose of used oil properly. Contact your local authorities for approved disposal methods or possible recycling.**

- Install the drain plug with its gasket, tightening it to 20 N-m (2.0 kg-m, 14.5 ft-lb) of torque.
- Remove the oil filler opening plug, and pour in 850 mL (0.90 US qt) [KX125: 700 mL (0.74 US qt), KX500: 800 mL (0.85 US qt)] of fresh transmission oil.
- Check the oil level, after kicking the kick pedal 3 or 4 times.
- Install the oil filler opening plug.

## Cooling System

### *Radiator Hoses*

Check the radiator hoses for cracks or deterioration, and connections for looseness in accordance with the Periodic Maintenance Chart.

### *Radiator*

Check the radiator fins for obstruction by insects or mud. Clean off any obstructions with a stream of low-pressure water.

### CAUTION

Using high-pressure water, as from a car wash facility, could damage the radiator fins and impair the radiator's effectiveness.

Do not obstruct or deflect airflow through the radiator by installing unauthorized accessories in front of the radiator. Interference with the radiator airflow can lead to overheating and consequent engine damage.

### *Coolant*

Coolant absorbs excessive heat from the engine and transfers it to the air at the radiator. If the coolant level becomes low, the engine overheats and may suffer severe damage. Check the coolant level each day before riding the motorcycle and replenish coolant if the level is low.

### ⚠ WARNING


To avoid burns, do not remove the radiator cap or try to change the coolant when the engine is still hot. Wait until it cools down.

### NOTE

○ A permanent type of antifreeze is installed in the cooling system when shipped. It is colored green and contains ethylene glycol. It is mixed at 50% and has the freezing point of  $-35^{\circ}\text{C}$  ( $-31^{\circ}\text{F}$ ).

### *Coolant Level Inspection*

- Situate the motorcycle so that it is perpendicular to the ground.
- Remove the right radiator cover.
- Remove the radiator cap in two steps. First turn the cap counterclockwise to the first stop and wait there for a few seconds. Then push and turn it further in the same direction and remove the cap.




A. Radiator Cap  
B. Right Radiator Cover

- Check the coolant level in the radiator. The coolant level should be to the bottom of the radiator filler neck.

#### NOTE

- Check the level when the engine is cold (room or ambient temperature).



1. Coolant Level

2. Breather Hose

- If the coolant level is low, add the coolant through the filler opening to the bottom of the radiator filler neck.

#### Coolant

Water and coolant mixture ratio:

1 : 1 (Water 50%, Coolant 50%)

Recommended coolant:

Permanent type of antifreeze (soft water and ethylene glycol plus corrosion and rust inhibitor chemicals for aluminum engines and radiators)

Total amount:

KX125 : 0.97 L (1.0 US qt)

KX250 : 1.18 L (1.3 US qt)

KX500 : 1.3 L (1.4 US qt)


- Install the radiator cap and right radiator cover.

### Coolant Change

The coolant should be changed periodically to ensure long engine life.

- Wait the engine to cool completely.
- Situate the motorcycle so that it is perpendicular to the ground.
- Remove the right radiator cover and radiator cap.
- Place a container under the coolant drain plug, and drain the coolant from the radiator and engine by removing the drain plug at the water pump cover. Immediately wash out any coolant that spills on the frame, engine, or wheel.


#### KX125



A. Water Pump Cover

B. Drain Plug


#### KX250:



A. Water Pump Cover

B. Drain Plug

**KX500:**



**A. Water Pump Cover**

**B. Drain Plug**


- For KX250, place a container under the drain plug on the right side of the cylinder and drain the coolant by removing the drain plug.



**A. Drain Plug (KX250)**

- For KX500, place a container under the hose fitting on the right side of the cylinder and drain the coolant by removing the hose fitting.





A. Hose Fitting (KX500)

**⚠ WARNING**

Coolant on tires will make them slippery and can cause an accident and injury.

- Visually inspect the old coolant. If whitish cotton-like wafts are observed, aluminum parts in the cooling system are corroded. If the coolant is brown, iron or steel parts are rusting. In either case, flush the cooling system.
- Check the cooling system for damage, loose joints, or leaks.
- For KX500, install the hose fitting.

- Install the water pump cover drain plug and cylinder drain plug (KX250) with the specified torques shown in the table. Always replace the gasket with a new one, if it is damaged.

**Drain Plug Tightening Torque**

<p>Water Pump Cover Plug: 9 N·m (0.9 kg·m, 78 in·lb) Cylinder Drain Plug (KX250): 9 N·m (0.9 kg·m, 78 in·lb)</p>
--------------------------------------------------------------------------------------------------------------------------

- Fill the radiator up to the bottom of the radiator filler neck with coolant, and install the radiator cap.
- Check the cooling system for leaks.
- Start the engine, warm up the engine thoroughly, then stop the engine.
- Check the coolant level after the engine cools down. If the coolant level is low, add the coolant up to the bottom of the radiator filler neck.
- Install the radiator cap and right radiator cover.

## Spark Plug

The standard spark plug is shown in the table. Spark plug should have a specified gap, and be tightened to 27 N-m (2.8 kg-m, 20 ft-lb) of torque.


### Standard Spark Plug

KX125	NGK BR9EVX
KX250	NGK BR8EVX
KX500	NGK BR8EG

### Spark Plug Gap

NGK BR7EVX, BR8EVX, BR9EVX	0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
NGK BR8EG, BR7EG, BR9EG	0.5 ~ 0.6 mm (0.020 ~ 0.024 in)

## Spark Plug Gap



### 1. Gap

The spark plug should be taken out periodically to check its gap and ceramic insulator. If the plug is oily or has carbon built up on it, clean it (preferably with a sandblaster) and then clean off any abrasive particles. The plug may also be cleaned using a high flash-point solvent and a wire brush or other suitable tool. Measure the gap with a wire-type thickness gauge, and adjust the gap, if incorrect, by bending the outer electrode. If the spark plug electrodes are corroded, or damaged, or if insulator is cracked, replace the plug.

To find out whether the right temperature plug is being used, pull it out and examine the ceramic insulator around the center electrode. If the ceramic is light brown, the spark plug is correctly matched to engine temperature. If the ceramic is burned white, the plug should be replaced.

with the next colder plug. If the ceramic is black, the plug should be replaced with the next hotter plug.

### Replace Spark Plug

	Colder Plug	Hotter Plug
KX125	NGK BR10EVX	NGK BR8EVX
KX250	NGK BR9EVX	NGK BR7EVX
KX500	NGK BR9EG	NGK BR7EG

### NOTE

○ *If the engine performance drops, replace the spark plug first to regain performance.*


## Ignition Timing

Because a capacitor discharge ignition (CDI) system is used on this motorcycle, the ignition timing should never require adjustment unless the magneto stator is incorrectly installed during engine reassembly. However, if there is any doubt as to the timing, inspect and adjust, if necessary, as follows:

### *Ignition Timing Adjustment*

- Remove the magneto cover.
- Check to see if the center mark of the three marks on the magneto stator is aligned with the mark on the crankcase.


**KX125:**



**A. Timing Mark (Crankcase)**  
**B. Timing Mark (Stator Plate)**

**C. Magneto Stator**  
**D. Screw**


**KX250:**



**A. Timing Mark (Crankcase)**  
**B. Timing Mark (Stator Plate)**

**C. Magneto Stator**  
**D. Screw**

### KX500:



A. Timing Mark (Crankcase)

B. Timing Mark (Stator Plate)


- If the marks are not aligned, loosen the magneto stator screws and turn the magneto stator.
- Tighten the screws securely.
- Install the magneto cover.

### KX125, 250:

The ignition timing can be adjusted for different power bands to suit the rider's preference and ability.

- Remove the magneto cover.
- Loosen the stator screws.
- Adjust the timing by shifting the stator position within the three lines.

### KX125:



A. Timing Mark (Crankcase)


B. Standard Timing Mark

C. Adjustable Range

D. Stator Plate

E. Screw

## KX250:



A. Timing Mark (Crankcase)  
B. Standard Timing Mark  
C. Adjustable Range


D. Stator Plate  
E. Screw

### NOTE

○ For best engine performance, it is very important to adjust the ignition timing within the adjustable range just explained.

- Tighten the stator screws securely.
- Install the magneto cover.
- Test ride the motorcycle and readjust the ignition timing if necessary.


## KX125:



A. Crankshaft Rotation  
B. Stator Movement

C. Advance  
D. Retard

KX250:



A. Crankshaft Rotation  
B. Stator Movement

C. Advance  
D. Retard

## Air Cleaner

A clogged air cleaner restricts the engine's air intake, increasing fuel consumption, reducing engine power, and causing spark plug fouling.

### **⚠ WARNING**

A clogged air cleaner may allow dirt and dust to enter the carburetor and stick the throttle open. This could cause an accident.


### **CAUTION**

A clogged air cleaner may allow dirt and dust to enter the engine causing excessive wear and possible engine damage.

Inspect the element, without fail, before and after each racing or practice session. Clean it if necessary.

### *Element Removal*

- Remove the seat.
- Remove the wing bolt, and take out the element.




A. Seat


B. Seat Mounting Bolt

KX125, 250:

KX500:



A. Element




B. Wing Bolt

### *Element Cleaning*

- Check inside the inlet track and carburetor for dirt. If dirt is present, clean the intake tract and carburetor thoroughly. You may also need to replace the air cleaner element and seal the air cleaner housing and inlet tract.
- Stuff a clean, lint-free towel into the carburetor so no dirt is allowed to enter the carburetor.
- Wipe out the inside of the air cleaner housing with a clean damp towel.
- Take the element off the frame.





A. Element

B. Frame



### CAUTION

Do not twist or wring the element, as it can easily be torn or otherwise damaged.

- Clean the element in a bath of a high flash-point solvent using a soft bristle brush. Squeeze it dry in a clean towel. Do not wring the element or blow it dry; the element can be damaged.

### **⚠ WARNING**

Clean the element in a well-ventilated area, and take care that there are no sparks or flame anywhere near the working area; this includes any appliance with a pilot light. Do not use gasoline or a low flash-point solvent to clean the element. A fire or explosion could result.

- Inspect the element for damage such as tears, hardening, or shrinkage. If damaged, replace it or it will allow dirt into the carburetor.

### **⚠ WARNING**


If dirt or dust is allowed to pass through into the carburetor, the throttle may become stuck, possibly causing an accident.

### **CAUTION**

If dirt gets through into the engine, excessive engine wear and possibly engine damage will occur.

- After cleaning, saturate the element with a high-quality foam-air-filter oil, squeeze out the excess oil, then wrap it in a clean rag and squeeze it as dry as possible. Be careful not to tear the element.
- Apply grease to all connections and screw hole in the air cleaner housing and intake tract.
- Remove the towel from the carburetor.

- Install the element on the frame, and coat the lip of the element with a thick layer of all purpose grease to assure a complete seal against the element base. Also, coat the base where the lip of the element fits.



A. Grease


- Install the element in the machine, and make sure the sealing surface of the element is seated properly.
- Install the seat.

## Throttle Cable

Inspect the throttle grip for smooth operation in all steering positions. Adjust the throttle grip play in accordance with the Periodic Maintenance Chart.

- Check that the throttle grip has 2 – 3 mm (0.08 – 0.12 in) of play and turns smoothly.
- ★ If the play is incorrect, loosen the locknut on the upper end of the throttle cable, and turn the adjuster to obtain the correct amount of play. Tighten the locknut.


KX125, 250:



A. Adjuster  
B. Locknut

C. Throttle Grip  
D. 2 – 3 mm (0.08 – 0.12 in)


KX500:



A. Adjuster  
B. Locknut

C. Throttle Grip  
D. 2 – 3 mm (0.08 – 0.12 in)

★ If the free play cannot be set by adjusting the upper cable adjuster, pull the rubber boot off of the carburetor top. Make the necessary free play adjustment at the lower cable adjuster, then tighten the locknut and reinstall the rubber boot.



A. Locknut


B. Adjuster

## Carburetor

### *Idling Adjustment*

Idling adjustment is carried out using the air screw and idle adjusting screw.

- First turn in the air screw until it seats lightly, and back it out 1½ turns.
- After thoroughly warming up the engine, turn the idle adjusting screw to obtain the desired idle speed. If no idle is preferred, turn out the screw until the engine stops.



A. Idle Adjusting Screw

B. Air Screw

- Open and close the throttle a few times to make sure the idle speed does not change. Readjust if necessary.
- With the engine idling, turn the handlebar to each side. If handlebar movement changes the idle speed, the throttle cable may be improperly adjusted or incorrectly routed, or it may be damaged. Be sure to correct any of these conditions before riding.

### **⚠ WARNING**


Operation with a damaged cable could result in an unsafe riding condition.

## Clutch

Proper clutch lever play between the clutch lever and the clutch lever holder is 2 – 3 mm (0.08 – 0.12 in). Play increases with cable stretch and friction plate wear, necessitating adjustment.

When there is too much lever play, first try adjusting the cable at the clutch lever.

- Slide the clutch lever dust cover out of place.
- Loosen the knurled locknut, turn the adjuster to obtain the proper amount of lever play, and tighten the locknut.




- A. Clutch Lever                      C. Adjuster  
B. Knurled Locknut                D. 2 – 3 mm (0.08 – 0.12 in)

- Slide back the clutch lever dust cover.

If the adjuster at the clutch lever has reached its limit, adjust the cable with the adjusting nut at the upper of the clutch cable.

- Loosen the knurled locknut at the clutch lever.
- Turn the adjuster in all the way, then tighten the knurled locknut.
- Loosen the locknut at the upper of the clutch cable, and turn the adjusting nut so that the clutch lever has 2 – 3 mm (0.08 – 0.12 in) of play.



- A. Adjusting Nut                      B. Locknut

- Tighten the locknut.
- Slide the dust cover back into place.

## Exhaust System


The muffler and silencer reduce exhaust noise and conduct the exhaust gases back away from the rider while keeping power loss to a minimum. If carbon built up inside the muffler, exhaust efficiency is reduced. This lowers engine power.

If the muffler is badly damaged, dented, cracked or rusted, replace it with a new one. Replace the silencer packing if the exhaust noise becomes too loud or the engine performance drops.

### *Silencer Packing Change*

- Remove the right side cover.
- Remove the silencer mounting bolts and pull the silencer off toward the rear.


KX125, 250:



A. Silencer

B. Mounting Bolts

**KX500:**




**A. Silencer**

**B. Mounting Bolts**


- Remove the inner pipe mounting bolts, and pull out the inner pipe.
- Pull off the old silencer packing, and install the new silencer packing.
- Install the inner pipe into the silencer.
- Install the silencer and right side cover.

**KX125, 250:**



**A. Mounting Bolts**


**KX500:**



**B. Inner Pipe**




KX125, 250:



A. Silencer Packing

KX500:



## Drive Chain


The drive chain must be checked, adjusted, and lubricated in accordance with the Periodic Maintenance Chart for safety and to prevent excessive wear. If the chain becomes badly worn or maladjusted – either too loose or too tight – the chain could jump off the sprockets or break.

### **▲WARNING**

A chain that breaks or jumps off the sprockets could snag on the engine sprocket or lock the rear wheel, severely damaging the motorcycle and causing it to go out of control.

### *Slack Inspection*

With the motorcycle on the side stand, push up the drive chain in the middle of the upper run to measure the chain play. The space between the chain and the swing-arm at the rear of the chain slipper should be 60 – 70 mm (2.4 – 2.8 in). Rotate the rear wheel to find the place where the chain is tightest (because it wears unevenly). Adjust the drive chain if it has too much or too little slack.



A. 60 – 70 mm (2.4 – 2.8 in)


In addition to checking the slack, rotate the rear wheel to inspect the drive chain and sprockets for damaged rollers, loose pin and links, unevenly or excessively worn teeth, and damaged teeth.

If there is any irregularity, replace the drive chain and/or sprockets.

### Slack Adjustment

- Remove the cotter pin.
- Loosen the rear axle nut and both chain adjuster locknuts.
- Turn both chain adjusting bolts evenly until the drive chain has 60 – 65 mm (2.4 – 2.6 in) of space between

the chain and the swingarm. To keep the chain and wheel aligned, the notch on the left chain adjuster should align with the same swingarm mark that the notch on the right chain adjuster aligns with.



- |                   |               |
|-------------------|---------------|
| A. Axle Nut       | D. Marks      |
| B. Adjusting Bolt | E. Notch      |
| C. Locknut        | F. Cotter pin |

### NOTE

- Wheel alignment can also be checked using the straightedge or string method.

### **⚠ WARNING**

Misalignment of the wheel will result in abnormal wear and may result in an unsafe riding condition.

- Tighten both chain adjuster locknuts.
- Tighten the axle nut to 113 N-m (11.5 kg-m, 83 ft-lb) of torque.
- Rotate the wheel, measure the chain slack again at the tightest position, and readjust if necessary.
- Install a new cotter pin through the axle nut and axle, and spread its ends.

### ⚠ WARNING

If the axle nut is not securely tightened or the cotter pin is not installed, an unsafe riding condition may result.

### NOTE


- In wet and muddy conditions, mud sticks to the chain and sprockets resulting in an overly tight chain, and the chain may break. To prevent this, adjust the chain to 70 – 75 mm (2.8 – 3.0 in) of space between the chain and swingarm whenever necessary.

### Drive Chain, Chain Guide, Chain Slipper and Sprockets Wear Inspection

When the chain has worn so much that it is more than 2% longer than when new, it is no longer safe for use and should be replaced. Whenever the chain is replaced, inspect both the engine and rear sprockets, and replace them if necessary. Overworn sprockets will cause a new chain to wear quickly.

### Drive Chain Wear

Since it is impractical to measure the entire length of the chain, determine the degree of wear by measuring a 20-link length of the chain. Stretch the chain taut either by using the chain adjuster, or by hanging a 10 kg (20 lb) weight on the chain. Measure the length of 20 links on a straight part of the chain from the center of the 1st pin to the center of the 21st pin. If the length is greater than the service limit, the chain should be replaced.



A. Weight


B. Measure

### Drive Chain Length

Standard	Service Limit
317.5 mm (12.5 in)	323 mm (12.7 in)

## NOTE

- *The drive system was designed for use with a DAIDO D.I.D 520DM 114 link chain (KX125: D.I.D 520DMA 112 link chain). For maximum stretch resistance and safety, a genuine part must be used for replacement.*
- *To minimize any chance of the master link coming apart, the master link clip must be installed with the closed end of the "U" points in the direction of chain rotation.*




A. Clip

B. Direction of Chain Rotation

## Chain Guide Wear


Visually inspect the drive chain guide. If the guide is worn excessively or damaged, replace it.



A. Chain Guide

## Chain Slipper Wear

Visually inspect the upper and lower chain slippers on the swingarm. If the chain slipper is worn or damaged, replace it.



**A. Chain Slippers**

**B. Swingarm**


### ***Sprocket Wear***

Visually inspect the sprocket teeth. If they are worn or damaged, replace the sprocket.

#### **NOTE**

○ *Sprocket wear is exaggerated for illustration.*


### **Sprocket**



### **Lubrication**

Lubrication is necessary after riding through rain or in the mud, or any time that the chain appears dry. A heavy oil such as SAE90 is preferred to a lighter oil because it will stay on the chain longer and provide better lubrication.


- Apply oil to the side of the rollers so that it will penetrate to the rollers and bushings. Wipe off any excess oil.



## Handlebar

### KX125:


- To keep the handlebar properly secured in place, it is necessary to correctly install the handlebar clamps.



A. Front

B. Arrow

- Tighten the clamp bolts, front first and then the rear, to 25 N-m (2.5 kg-m, 18 ft-lb) of torque. If the handlebar clamp is correctly installed, there will be no gap at the front and an even gap at the rear after tightening.



A. Front

B. No Gap


C. Gap

#### **KX250, 500:**

To suit various riding positions, the handlebar position can be adjusted by handlebar holder turn front to rear.

#### *Handlebar Position Adjustment*


- Remove the handlebar clamp and bolts, and take off the handlebar.
- Loosen the handlebar holder nuts, turn about the handlebar holder, and tighten the nuts securely.



A. Handlebar Holders

B. Nuts

- Put the handlebar on the handlebar holder.
- Mount the clamp so that the cut side on the clamp points toward the rear.



**A. Handlebar Clamp**

**C. Cut Side**

**B. Bolts**


- Tighten the clamp bolts, front first and then the rear, to 25 N-m (2.5 kg-m, 18 ft-lb) of torque. If the handlebar clamp is correctly installed, there will be no gap at the front and an even gap at the rear after tightening.

## Brakes

Disc and disc pad wear is automatically compensated for and has no effect on the brake lever or pedal action. So there are no parts that require adjustment on the brakes except brake lever position, brake pedal position (KX500) and pedal play (KX500).

### Front Brake Lever Position

Adjust the front brake lever position to suit you. To adjust the brake lever position, remove the cotter pin, loosen the locknut, and turn the adjuster to either side with a screwdriver. After adjustment, tighten the locknut securely, and install a new cotter pin through the adjuster and spread its ends.



**A. Brake Lever**

**B. Adjuster**


**C. Locknut**

**D. Cotter Pin**



### Rear Brake Pedal Position (KX500)

When the brake pedal is in rest position, it should be  $-10 \sim 10$  mm ( $-0.39 \sim 0.39$  in) from the top of the footpeg. If it is not, adjust the pedal position.




A. Rear Brake Pedal

B. Footpeg

C.  $-10 \sim 10$  mm ( $-0.39 \sim 0.39$  in)

- To adjust the pedal position, loosen the locknut, turn the adjusting bolt, and then tighten the locknut securely.



A. Locknut


B. Adjusting Bolt

- Adjust the brake pedal play.

### Rear Brake Pedal Play (KX500)

The brake pedal has  $10 \sim 20$  mm ( $0.39 \sim 0.79$  in) of play when the pedal is pushed down lightly by hand.

- To adjust the pedal play, loosen the locknut and turn the adjuster on the rear master cylinder.
- After adjustment, tighten the locknut securely.



- A. Rear Master Cylinder    D. Rear Brake Pedal  
 B. Adjuster                    E. 10 ~ 20 mm  
 C. Locknut                      (0.39 ~ 0.79 in)

- Check the brake for good braking power and no brake drag.

### ⚠ WARNING

If the brake lever or pedal feels mushy when it is applied, there might be air in the brake lines or the brake may be defective. Since it is dangerous to operate the motorcycle under such conditions, have the brake checked immediately.

### Disc Brake Fluid

In accordance with the Periodic Maintenance Chart, inspect the brake fluid level in the reservoirs and change the brake fluid. The brake fluid should also be changed if it becomes contaminated with dirt or water.

### Fluid Requirement

Recommended fluid are given in the table. If none of the recommended brake fluids are available, use extra heavy-duty brake fluid only from a container marked D.O.T.3 or D.O.T.4.

#### Recommended Disc Brake Fluid (D.O.T.3)

Atlas Extra Heavy Duty
Shell Super Heavy Duty
Texaco Super Heavy Duty
Wagner Lockheed Heavy Duty
Castrol Girling-Universal
Castrol GT (LMA)
Castrol Disc Brake Fluid

#### (D.O.T.4)

Castrol Girling-Universal
Castrol GT (LMA)
Castrol Disc Brake Fluid
Check Shock Premium Heavy Duty

### NOTE

- Brake fluid of D.O.T.4 is installed in the brake system when shipped.


## CAUTION

Do not spill brake fluid onto any painted surface.  
Do not use fluid from a container that has been left open or that has been unsealed for a long time.  
Check for fluid leakage around the fittings.  
Check for brake hose damage.


### *Fluid Level Inspection*

#### Front Reservoir:

- With the front reservoir held horizontal, the brake fluid level must be kept above the lower level line.



A. Front Reservoir  
B. Lower Level Line




C. Upper Level Line

- If the fluid level in front reservoir is lower than the lower level line, check for fluid leaks in the brake line, and fill the reservoir to the upper level line. Inside the front reservoir is a stepped end showing the upper level line.

#### Rear Reservoir:


- With the rear reservoir held horizontal, the brake fluid level must be kept more than half full.
- If the amount of brake fluid is insufficient, check for fluid leaks in the brake line, and add the brake fluid.

#### KX125, 250



A. Rear Reservoir

KX500:



A. Rear Reservoir


### **⚠ WARNING**

Do not mix two brands of fluid. Change the brake fluid in the brake line completely if the brake fluid must be refilled but the type and brand of the brake fluid already in the reservoirs are unidentified.

### **Brake Wear Inspection**

In accordance with the Periodic Maintenance Chart, inspect the brakes for wear. For each front and rear disc brake caliper, if the thickness of either pad is less than 1 mm (0.04 in), replace both pads in the caliper as a set. Pad replacement should be done by an authorized Kawasaki dealer.


### **Pad Usable Range**



## Steering


The steering should always be kept adjusted so that the handlebar will turn freely but not have excessive play.

To check the steering adjustment, using the jack (special tool), raise the front wheel off the ground. Push the handlebar lightly to either side; if it continues moving under its own momentum, the steering is not too tight. Squatting in front of the motorcycle, grasp the lower ends of the front fork at the axle, and push and pull the bottom end of the front fork back and forth; if play is felt, the steering is too loose.



### If the steering needs adjusting


- For KX250, 500 models, remove the number plate.
- Using the jack (special tool), raise the front wheel off the ground.
- Remove the handlebar.
- For KX125 model, loosen the front fork lower clamp bolts and steering stem head nut.



A. Stem Head Nut

B. Handlebar

- For KX250, 500 models, loosen the front fork upper clamp bolts, and remove the steering stem head nut and washer, and take off the steering stem head.




**A. Stem Head Nut**  
**B. Stem Head**

**C. Upper Clamp Bolts**

- Turn the steering stem locknut with the stem nut wrench (special tool) to obtain the proper adjustment.


#### KX125:



**A. Stem Locknut**

**B. Stem Nut Wrench: 57001-1100**

## KX250, 500:



**A. Stem Locknut**      **B. Stem Nut Wrench: 57001-1100**

- For KX250, 500 models, install the stem head.
- Tighten the steering stem head nut, and front fork upper or lower clamp bolts to the specified torque.

### Tightening Torque

#### Stem Head Nut:

KX125, 250:      78 N-m (8.0 kg-m, 58 ft-lb)

KX500:            44 N-m (4.5 kg-m, 33 ft-lb)

#### Front Fork Clamp Bolts:

Upper:            22 N-m (2.25 kg-m, 16.3 ft-lb)

Lower:            20 N-m (2.0 kg-m, 14.5 ft-lb)

- Check the steering again, and readjust it if necessary.
- Install the parts removed.

## Front Fork

The front fork should always be adjusted for the rider's weight and track conditions by using one or more of the following methods.

Basically, there are five adjustments you can make to the front fork.

- ★ **Air pressure** – Air pressure acts as a progressive spring and affects the entire range of fork travel. The air pressure in the fork increases as the fork heats up, so the fork action on your KX will get stiffer as the race progresses. Because of this, we don't recommend using air pressure for additional springing. Your KX forks are designed to work without adding any air.
- ★ **Rebound damping adjustment** – This adjustment affects how quickly the rebound. The fork rebound damping adjuster has 18 clicks or more. The seated position (full clockwise until the adjuster stops) is full hard. From the point, 12 (KX250:11, KX500:10) clicks counterclockwise is the standard setting, and 18 clicks or more counterclockwise is full soft.
- ★ **Compression damping adjustment** – This adjustment affects how quickly the compresses. The fork compression damping adjuster has 18 clicks or more. The seated position (full clockwise until the adjuster stops) is full hard. From the point, 12 (KX250, 500:10) counterclockwise is the standard setting, and 18 clicks or more counterclockwise is full soft.
- ★ **Oil level adjustment** – The effects of higher or lower fork oil level are only felt during the final 100 mm (4 in) of fork travel. A higher oil level (more oil) will make the

fork rebound more quickly. A lower oil level (less oil) will make the fork rebound more slowly.

- ★ Fork springs – Optional springs are available that are softer and stiffer than standard.
- ★ Fork clamp position – Steering qualities are greatly affected by the fork clamp position (the amount of the outer tube projecting above the steering stem head). When the fork tube height is smaller, the front end becomes lighter due to change in weight bias. Also, it tends to understeer in turns and “wash out.” When the height is greater, the result is opposite. Be sure the front tire doesn’t rub the fender when the fork tubes compress fully. Make this adjustment in 10 mm (0.4 in) increments.


### CAUTION

The fork tubes, both right and left, should be adjusted evenly.

#### Air Pressure

The standard air pressure in the front fork legs is atmospheric pressure. The air pressure in the fork legs increases as the fork heats up, so the fork action will get stiffer as the vehicle operation progresses.

- Using the jack (special tool) raise the front wheel off the ground.
- Remove the screws at the top of the front fork top bolts to let the air pressure equalize. Then reinstall them.




A. Screw

#### Rebound Damping Adjustment


- To adjust rebound damping, turn the adjuster on the front fork top bolts with the blade of a screwdriver until you feel a click. Adjust the rebound damping to suit your preference under special conditions.





**A. Adjuster**

### Rebound Damping Adjustment



**A. Seated position with adjuster turned fully clockwise.**

### Standard Rebound Damping Adjuster Setting (turn the adjuster counterclockwise)


KX125	12 clicks
KX250	11 clicks
KX500	10 clicks

### CAUTION

The left and right fork tube must have the same shock damping.


### Compression Damping Adjustment

- Clean the bottom of the fork tubes.
- Remove the caps on the bottom of the fork tubes.
- To adjust compression damping, turn the adjuster on the front fork cylinder valve with the blade of a screwdriver until you feel a click. Adjust the compression damping to suit your preference under special conditions.



A. Adjuster

### Compression Damping Adjustment



A. Seated position with adjuster turned fully clockwise.

### Standard Compression Damping Adjuster Setting (turn the adjuster counterclockwise)

KX125	12 clicks
KX250	10 clicks
KX500	10 clicks


### CAUTION

The left and right fork legs must have the same shock damping.

- Put the caps into the bottom of the fork tubes.

### Oil Level Adjustment

- Using the jack (special tool) raise the front wheel off the ground.
- Remove the front fender.
- Remove the brake hose clamp.




**A. Brake Hose Clamp**

**B. Mounting Bolt(s)**

**C. Front Fork Protector**

**D. Brake Hose Guide**




**A. Inner Tube**

**B. Outer Tube**


**C. Dust Cover**

- Remove the front fork protectors.
- Remove the brake hose guide.
- Remove the handlebar clamp bolts and take out the handlebar.
- Loosen the fork upper clamp bolts.
- Remove the top bolts from the top of the fork tubes.
- Slowly compress front fork fully while pushing up the inner tube lower end (touch a stepped portion of the inner tube to the outer tube dust cover lower end), and place a stand or other suitable support under the front wheel.



- Pull down the fork spring and insert the spring holder (special tool) under the push rod nut or piston holder.


**KX125, 250:**



**A. Spring**  
**B. Push Rod Nut**

**C. Spring Holder: 57001-1286**


**KX500:**



**A. Spring**  
**B. Piston Holder**

**C. Spring Holder: 57001-1286**

- Holding the push rod nut with a wrench, loosen and remove the top bolt from the top of the push rod.
- Remove the fork spring seat.
- Take the spring holder (special tool) off and pull out the fork spring.



A. Top Bolt  
 B. O-Ring  
 C. Spring Seat  
 D. Wrench  
 E. Spring


- Remove the other fork spring.
- Put the oil level gauge (special tool) on the top of the fork tube, and measure the distance from the top of the fork tube to the oil level.

**Standard Oil Level:**

90 mm (3.54 in)

**Adjustable Range:**

80 – 110 mm (3.15 – 4.33 in)




A. Oil Level Gauge: 57001-1290

- Adjust the oil level as required within the adjustable range using the following oil.

Recommended Oil: KAYABA 01 or SAE 5W20

- Screw in the push rod puller (special tool) onto the push rod.




**A. Push Rod**

**B. Push Rod Puller: 57001-1289**

- Pull up the push rod slowly.
- At this time, the fork oil comes out of the push rod hole, let it overflow until it stops.
- Put the fork spring into the fork tube.
- Put the fork spring seat on the fork spring.
- Pull down the fork spring and insert the spring holder (special tool) under the push rod nut or piston holder.

**KX125, 250:**




**A. Spring**

**B. Spring Seat**

**C. Push Rod Nut**


**D. Spring Holder: 57001-1286**

**KX500:**




**A. Spring**                      **C. Spring Holder: 57001-1286**  
**B. Piston Holder**

- Remove the push rod puller.
- Check the O-ring of the top bolt for damage. If necessary, replace them.



**A. Top Bolt**                      **C. Spring**  
**B. O-Ring**

- Holding the top bolt with a wrench, tighten the push rod nut against the top bolt. Tighten the push rod nut to 28 N-m (2.85 kg-m, 20.6 ft-lb) of torque.



A. Top Bolt

B. Push Rod Nut

C. Wrench

- Remove the spring holder.
- Install the top bolt on the top of the fork tube and tighten it to 29 N-m (3.0 kg-m, 22 ft-lb) of torque.
- Assemble the other fork tube.
- Tighten the fork upper clamp bolts to 22 N-m (2.25 kg-m, 16.3 ft-lb) of torque.
- Install the parts removed.

### Fork Spring

Different fork springs are available to achieve suitable front fork action in accordance with the rider's weight and track condition.

- ★ Harder springs make the fork stiffer, and rebound action quicker.
- ★ Softer springs make the fork softer, and rebound action slower.

### Fork Clamp Position Adjustment


Steering qualities are greatly affected by the fork clamp position (the amount of the outer tube projecting above the steering stem head). When the fork tube height is smaller, the front end becomes lighter due to change in weight bias. Also, it tends to understeer in turns and "wash out." When the height is greater, the results are opposite.

Be sure the front tire doesn't rub the fender when the fork tubes compress fully. Make this adjustment in 10 mm (0.4 in) increments.

### CAUTION

The fork tubes, both right and left, should be adjusted evenly.





**A. Standard Fork Tube Height:**  
KX125, 250 : 5 mm (0.2 in.)  
KX500 : 0 mm

## Rear Suspension (Uni-Trak)

The rear suspension system of this motorcycle is Uni-trak. It consists of a rear shock absorber, swingarm, tie rod and rocker arm.

In general the operating characteristics of the Uni-trak are similar to the front fork. But, in achieving progressive spring characteristics a linkage system is used.


To suit to various riding conditions, the spring preload of the shock absorber can be adjusted or the spring can be replaced with an optional one. Also the damping force can be adjusted easily so changing oil viscosity is unnecessary.

## Shock Damping Adjustment:

### Rear Shock Absorber

#### *Rebound Damping Adjustment*

To adjust shock rebound damping, turn the rebound damping adjuster on the rear shock absorber lower end with the blade of a screwdriver until you feel a click.




A. Rebound Damping Adjuster

B. Mark

If the damper setting feels too soft or too stiff, adjust it in accordance with the following table.

## Rebound Damping Adjustment



A. Seated position with adjuster turned fully clockwise.

**Standard Rebound Damping Adjuster Setting**  
(turn the adjuster counterclockwise)

KX125	12 clicks
KX250	11 clicks
KX500	11 clicks


## Gas Reservoir

### *Compression Damping Adjustment*

To adjust compression damping, turn the compression damping adjuster on the gas reservoir with the blade of a screwdriver until you feel a click.

If the damper setting feels too soft or too stiff, adjust it in accordance with the following table.


## Compression Damping Adjustment



A. Seated position with adjuster turned fully clockwise.

### Standard Compression Damping Adjuster Setting (turn the adjuster counterclockwise)

KX125	12 clicks
KX250	12 clicks
KX500	10 clicks




A. Compression Damping Adjuster

B. Mark

### Spring Preload Adjustment:

- Remove the seat, right and left side covers.
- Loosen the air cleaner duct clamp screw.
- Remove the silencer.
- Remove the rear frame with the air cleaner case.


**KX125, 250:**



**A. Rear Frame**

**B. Air Cleaner Case**

**KX500:**




**A. Rear Frame**

**B. Air Cleaner Case**


- Place a jack (special tool) under the frame so that the rear wheel is raised off the ground.
- Using the hook wrenches (special tools), loosen the locknut and turn the adjusting nut as required. Turning the adjusting nut down makes the spring preload stronger.

### KX125, 250:



A. Adjusting Nut  
B. Locknut  
C. Hook Wrenches: 57001-1101


### KX500:



A. Adjusting Nut  
B. Locknut  
C. Hook Wrenches: 57001-1101

- For KX125, standard spring preload is 541 N (55.2 kg, 122 lb). The adjusting nut changes the preload 68 N (6.9 kg, 15.2 lb) turn.
- For KX250, standard spring preload is 631 N (64.4 kg, 142 lb). The adjusting nut changes the preload 71 N (7.2 kg, 15.9 lb) turn.
- For KX500, standard spring preload is 809 N (82.5 kg, 182 lb). The adjusting nut changes the preload 81 N (8.25 kg, 18.2 lb) turn.
- For KX125, the standard adjusting nut position from the center of the upper mounting hole is 110 mm (4.33 in). The adjustable range is 99.5 – 118 mm (3.92 – 4.65 in).

- For KX250, the standard adjusting nut position from the center of the upper mounting hole is 111 mm (4.37 in). The adjustable range is 99.5 – 118 mm (3.92 – 4.65 in).
- For KX500, the standard adjusting nut position from the center of the upper mounting hole is 117.5 mm (4.63 in). The adjustable range is 104 – 127 mm (4.09 – 5.0 in).



A. Adjusting Nut Position.    C. Adjusting Nut  
B. Locknut

- Tighten the locknut securely.
- After adjustment, move the spring up and down to make sure that the spring is seated.
- Install the parts removed.

### Rear Shock Absorber Spring Replacement

In addition to the standard spring, hard and soft springs are available. If the standard spring is improper for your purpose, select a proper one according to the rider's weight or course conditions.

- ★ **Using the harder spring:** The spring rate is higher; the spring is stiffer and rebounds more quickly.
- ★ **Using the softer spring:** The spring rate is lower; the spring is softer and rebounds more slowly.

### ⚠ WARNING

Improper removal by spring from rear shock absorber body may cause the spring and/or associated parts to be ejected at high velocity. Always wear eye and face protection. Removal and installation of spring should be performed by an authorized Kawasaki dealer.

## Wheels

### Tires

Tire pressure affects traction, handling, and tire life. Adjust the tire pressure to suit track conditions and rider preference, but do not stray too far from the recommended pressure.


#### NOTE

- *Tire pressure should be checked when the tires are cold before your ride.*

Track Condition	Tire Pressure
○ When the track is wet, muddy, sandy or slippery, reduce the tire pressure to increase the tire tread surface on the ground.	80 kPa (0.8 kg/cm <sup>2</sup> , 11 psi)
	↕
○ When the track is pebbly or hard, increase the tire pressure to prevent damage or punctures, though the tires will skid more easily.	100 kPa (1.0 kg/cm <sup>2</sup> , 14 psi)

### Spokes and Rim


The spokes on both wheels must all be tightened securely and evenly and not be allowed to loosen. Unevenly tightened or loose spokes will cause the rim to warp, hasten nipple and overall spoke fatigue, and may result in spoke breakage.



**A. Spoke and Spark Plug Wrench**

### Bead Protector

There is a bead protector on the front and rear wheels. The bead protector prevents the tire and tube from slipping on the rim and damaging the valve stem. Valve stem damage may cause the tube to leak, necessitating tube replacement. In order that the tire and tube remain fixed in position on the rim, inspect the bead protector before riding and tighten it if necessary. Tighten the valve stem nut finger tight only.



**A. Bead Protector Nut**

### Rim Runout


Set a dial gauge to the side of the rim, and rotate the wheel to measure axial runout. The difference between the highest and lowest dial readings is the amount of runout.

Set the dial gauge to the inner circumference of the rim and rotate the wheel to measure radial runout. The difference between the highest and lowest dial readings is the amount of runout.

A certain amount of rim warp (runout) can be corrected by recentering the rim, that is, loosening some spokes and tightening others to change the position of different parts of the rim. If the rim is badly bent, however, it should be replaced.

### NOTE


○ *Weld area of the rim may show excessive runout. Disregard this when measuring runout.*






### Rim Runout

	Service Limit
Axial	2.0 mm (0.08 in)
Radial	



A. Axial Runout




A. Radial Runout

## Bolt and Nut Tightening

Every day before riding, check without fail the tightness of the bolts and nuts described here. Also, check to see whether or not each cotter pin is in place and in good condition.


### KX125, 250



1. Front Fork Clamp Bolts
2. Handlebar Clamp Bolts
3. Clutch Lever Mounting Bolt
4. Spark Plug
5. Cylinder Head Nuts
6. Cylinder Nuts
7. Rear Frame Mounting Bolts
8. Air Cleaner Case Bolts


9. Seat Mounting Bolt
10. Spokes
11. Disc Plate Screws
12. Front Axle Clamp Nuts
13. Brake Hose Clamp Bolts
14. Fork Protector Mounting Bolts
15. Bead Protector Nut
16. Caliper Mounting Bolts

### KX500:



17. Fork Protector Guide Mounting Bolt
18. Front Fender Mounting Bolts
19. Radiator Mounting Bolts
20. Engine Mounting Bolts
21. Shift Pedal Bolt
22. Chain Guide Bolts
23. Chain Adjuster Locknut

## KX125, 250:




- 24. Rear Axle Nut
- 25. Silencer Mounting Bolts
- 26. Rear Brake Reservoir Mounting Bolt or Screw
- 27. Rear Shock Absorber Bolts

- 28. Muffler Mounting Bolt and Nut
- 29. Engine Bracket Bolts
- 30. Steering Stem Head Nut
- 31. Brake Lever Mounting Bolt
- 32. Tie Rod Mounting Bolt

- 33. Rear Brake Pedal Bolt
- 34. Rocker Arm Mounting Bolt
- 35. Pivot Shaft Nut
- 36. Kick Pedal Bolt

## KX500



## Torque Table

Tighten all bolts and nuts to the proper torque using an accurate torque wrench. A bolt or nut if insufficiently tightened may become damaged or fall out, possibly resulting in damage to the motorcycle and injury to the rider. A bolt or nut which is over-tightened may become damaged or break and then fall out.

Part Name		N-m	kg-m	ft-lb
	Cylinder Drain Plug (KX250)	9	0.9	(78 in-lb)
	Cylinder Head Nuts	25	2.5	18
	Cylinder Nuts:			
	KX125	25	2.5	18
	KX250, 500	34	3.5	25
	Engine Drain Plug	20	2.0	14.5
	Kick Pedal Bolt:			
	KX125	9	0.9	78 (in-lb)
	KX250, 500	25	2.5	18
	Shift Pedal Bolt	10	1.0	87 (in-lb)
	Spark Plug	27	2.8	20
	Water Pump Cover Drain Plug	9	0.9	78 (in-lb)
	Caliper Mounting Bolts	25	2.5	18
	Disc Plate Mounting Screws	10	1.0	87 (in-lb)
	Engine Bracket Bolt:			
	M8	29	3.0	22
	M10	44	4.5	33
	Engine Mounting Bolts	44	4.5	33
	Front Axle	78	8.0	58
	Front Axle Clamp Nuts	9.3	0.95	83 (in-lb)
	Front Brake Hose Clamp Bolts	10	1.0	87 (in-lb)
	Front Fork Clamp Bolts			
	Upper	22	2.25	16.3
	Lower	20	2.0	14.5
	Front Fork Protector Guide Mounting Bolt	7.8	0.8	69 (in-lb)
	Front Fork Protector Mounting Bolts	10	1.0	87 (in-lb)

Part Name		N-m	kg-m	ft-lb
	Handlebar Clamp Bolts	25	2.5	18
	Pivot Shaft Nut	98	10.0	72
	Rear Axle Nut	113	11.5	83
	Rear Brake Pedal Bolt	25	2.6	19
	Rear Frame Mounting Bolts	34	3.5	25
	Rear Shock Absorber Bolts	39	4.0	29
	Spokes	2.2	0.22	19 (in-lb)
	Steering Stem Head Nut: KX125, 250	78	8.0	58
	KX500	44	4.5	33
	Steering Stem Locknut	4	0.4	35 (in-lb)
	Uni-trak Rocker Arm Bolt	88	9.0	65
	Uni-trak Tie Rod Bolts	83	8.5	61

## Cleaning

### 1) Preparation for washing

Before washing, precautions must be taken to keep water off the following places:

Rear opening of

the muffler ..... Cover with a plastic bag secured with rubber bands.

Clutch and brake levers,

hand grips, engine

stop button..... Cover with plastic bags.

Air cleaner intake.....

Close up the opening with tape, or stuff in rags.

### 2) Where to be careful

Avoid spraying water with any great force near the following places:

Disc brake master cylinders and calipers

Under the fuel tank .....

If water gets into the ignition coil or into the spark plug cap, the spark will jump through the water and be grounded out. When this happens, the motorcycle will not start and the affected parts must be wiped dry.

Front and rear hubs

Steering pivots (Steering stem head pipe)

Uni-trak system pivots

Swingarm pivot

### 3) After washing

- Remove the plastic bags, and clean the air cleaner intake.
- Lubricate the points listed in the Lubrication Section.
- Start the engine and run it for 5 minutes.
- Test the brakes before riding the motorcycle.

## WARNING

Never wax or lubricate the brake disc. Loss of braking and an accident could result. Clean the disc with an oil-less solvent such as trichloroethylene or acetone. Observe the solvent manufacturer's warning.

## Lubrication

Lubricate the points shown here, with either motor oil or regular grease, in accordance with the Periodic Maintenance Chart or whenever the vehicle has been operated under wet or rainy conditions, and especially after using a high pressure spray washer. Before lubricating each part, clean off any rusty spots with rust remover and wipe off any grease, oil, dirt, or grime.


### General Lubrication

Apply motor oil to the following pivots:


- Clutch Lever
- Front Brake Lever



- Rear Brake Pedal
- Rear Brake Rod Joints
- Kick Pedal




○Shift Pedal



**Use an aerosol cable lubricant with a pressure  
luber on all cables:**

- Clutch Inner Cable
- Throttle Inner Cable


**Cable Lubrication**





**Apply grease to the following points:**

- Clutch Inner Cable Upper End
- Throttle Inner Cable Upper End




**A. Grease.**

**Drive Chain Lubrication:**

Lubrication is also necessary after riding through rain or on wet track, or any time that the chain appears dry. A heavy oil such as SAE 90 is preferred to a lighter oil because it will stay on the chain longer and provide better lubrication.

- Apply oil to the side of the rollers so that it will penetrate to the rollers and bushings. Wipe off any excess oil.





### **Poor Running at Low Speed:**

#### **Spark weak:**

- Spark plug dirty, broken, or maladjusted
- Spark plug cap or high tension wiring trouble
- Spark plug cap shorted or not in good contact
- Spark plug incorrect
- Igniter trouble
- Ignition coil trouble
- Flywheel magneto damaged

#### **Fuel/air mixture incorrect:**

- Idle adjusting screw maladjusted
- Slow jet or air passage clogged
- Air cleaner element clogged, poorly sealed, or missing
- Starter plunger stuck open
- Fuel level too high or too low
- Fuel tank air vent obstructed
- Carburetor holder loose
- Air cleaner duct loose

#### **Compression low:**

- Spark plug loose
- Cylinder head not sufficiently tightened down
- Cylinder nut loose
- Cylinder, piston worn
- Piston ring bad (worn, weak, broken, or sticking)
- Piston ring/land clearance excessive
- Cylinder head gasket damaged
- Cylinder head warped
- Cylinder base gasket damaged
- Reed valve damaged

### **KIPS ports stuck open:**

- KIPS exhaust valve stuck open (valve seizure, or carbon accumulation)
- KIPS exhaust valves assembled incorrectly
- Exhaust advancer spring damaged
- Exhaust valve operating rod seizure
- Rod (for KIPS) seized in cylinder

#### **Other:**

- Igniter trouble
- Transmission oil viscosity too high
- Brake dragging

### **Poor Running or No Power at High Speed:**

#### **Firing incorrect:**

- Spark plug dirty, damaged, or maladjusted
- Spark plug cap or high tension wiring damaged
- Spark plug cap shorted or not in good contact
- Spark plug incorrect
- Igniter trouble
- Ignition coil trouble
- Flywheel magneto damaged

**Fuel/air mixture incorrect:**

- Main jet clogged or wrong size
- Jet needle or needle jet worn
- Jet needle clip in wrong position
- Fuel level too high or too low
- Air jet or air passage clogged
- Air cleaner element clogged, poorly sealed, or missing
- Starter plunger stuck open
- Fuel to carburetor insufficient
- Water or foreign matter in fuel
- Fuel tank air vent obstructed
- Carburetor holder loose
- Air cleaner duct loose
- Fuel tap clogged
- Fuel line clogged

**Compression low:**

- Spark plug loose
- Cylinder head not sufficiently tightened down
- Cylinder nut loose
- Cylinder, piston worn
- Piston ring bad (worn, weak, broken, or sticking)
- piston ring/land clearance excessive
- Cylinder head gasket damaged
- Cylinder head warped
- Cylinder base gasket damaged
- Reed valve damaged

**Engine rpm will not rise properly:**

- Starter plunger stuck open
- Float level too high or too low
- Main jet clogged
- Throttle valve does not fully open
- Air cleaner element clogged
- Muffler clogged
- Water or foreign matter in fuel
- Cylinder exhaust port clogged
- Brake dragging
- Clutch slipping
- Overheating
- Transmission oil level too high
- Transmission oil viscosity too high
- Crankshaft bearing worn or damaged

**KIPS ports stuck closed:**

- KIPS exhaust valves stuck closed (valve seizure, or carbon accumulation)
- KIPS exhaust valves assembled incorrectly
- KIPS ports clogged (carbon accumulation)
- Exhaust valve operating rod seizure
- Rod (for KIPS) seized in cylinder

**Knocking:**

- Carbon built up in combustion chamber
- Fuel poor quality or incorrect
- Spark plug incorrect
- Igniter trouble

## **Overheating:**

### **Firing incorrect:**

- Spark plug dirty, broken, or maladjusted
- Spark plug incorrect
- Igniter trouble

### **Fuel/air mixture incorrect:**

- Main jet clogged or wrong size
- Fuel level too low
- Carburetor holder loose
- Air cleaner element clogged, poorly sealed, or missing
- Air cleaner duct poorly sealed

### **Compression high:**

- Carbon built up in combustion chamber

### **Engine load faulty:**

- Brake dragging
- Clutch slipping
- Transmission oil level too high
- Transmission oil viscosity too high

### **Lubrication inadequate:**

- Transmission oil level too low
- Transmission oil poor quality or incorrect

### **Coolant incorrect:**

- Coolant level too low
- Coolant deteriorated

### **Cooling system component incorrect:**

- Radiator clogged
- Radiator cap trouble
- Water pump not rotating

## **Clutch Operation Faulty:**

### **Clutch slipping**

- No clutch lever play
- Clutch cable maladjusted
- Clutch inner cable catching
- Clutch plate worn or warped
- Clutch spring broken or weak
- Clutch release mechanism trouble
- Clutch hub or housing unevenly worn

### **Clutch not disengaging properly:**

- Clutch lever play excessive
- Clutch plate warped or too rough
- Clutch spring tension uneven
- Transmission oil deteriorated
- Transmission oil viscosity too high
- Transmission oil level too high
- Clutch housing frozen on drive shaft
- Clutch release mechanism trouble

## **Gear Shifting Faulty:**

### **Doesn't go into gear; shift pedal doesn't return:**

- Clutch not disengaging
- Shift fork bent or seized
- Gear stuck on the shaft
- Gear positioning lever binding
- Shift return spring weak or broken
- Shift return spring pin loose
- Shift mechanism arm spring broken
- Shift mechanism arm broken
- Shift drum broken

**Jumps out of gear:**

- Shift fork worn
- Gear groove worn
- Gear dogs and/or dog holes worn
- Shift drum groove worn
- Gear positioning lever spring weak or broken
- Shift fork pin worn
- Drive shaft, output shaft, and/or gear splines worn

**Overshifts:**

- Gear positioning lever spring weak or broken
- Shift mechanism arm spring broken

**Abnormal Engine Noise:****Knocking:**

- Igniter trouble
- Carbon built up in combustion chamber
- Fuel poor quality or incorrect
- Spark plug incorrect
- Overheating

**Piston Slap:**

- Cylinder/piston clearance excessive
- Cylinder, piston worn
- Connecting rod bent
- Piston pin, piston pin holes worn

**Other noise:**

- Connecting rod small end clearance excessive
- Connecting rod big end clearance excessive
- Piston ring worn, broken or stuck
- Piston seizure, damage
- Cylinder head gasket leaking
- Exhaust pipe leaking at cylinder head connection
- Crankshaft runout excessive

- Engine mounts loose
- Crankshaft bearing worn
- Primary gear worn or chipped

**Abnormal Drive Train Noise:****Clutch noise:**

- Clutch housing/friction plate clearance excessive
- Clutch housing gear/primary gear backlash excessive
- Metal chip jammed in clutch housing gear teeth

**Transmission noise:**

- Crankcase bearing worn or damaged
- Transmission gear worn or chipped
- Metal chip jammed in gear teeth
- Transmission oil insufficient or too thin
- Kick ratchet gear not properly disengaging from kick gear
- Output shaft idle gear worn or chipped

**Drive chain noise:**

- Drive chain adjusted improperly
- Chain worn
- Rear and/or engine sprocket(s) worn
- Chain lubrication insufficient
- Rear wheel misaligned

**Abnormal Frame Noise:****Front fork noise:**

- Oil insufficient or too thin
- Spring weak or broken

**Rear shock absorber noise:**

- Shock absorber damaged

**Disc brake noise:**

- Pad installed incorrectly
- Pad surface glazed
- Disc warped
- Caliper trouble
- Cylinder damaged

**Other noise**

- Bracket, nut, bolt, etc. not properly mounting or tightened

**Exhaust Smoke:****Excessive white smoke:**

- Throttle cable maladjusted

**Brownish smoke:**

- Air cleaner element clogged
- Main jet too large or fallen out
- Starter plunger stuck open
- Fuel level too high

**Handling and/or Stability Unsatisfactory:****Handlebar hard to turn:**

- Control cable routing incorrect
- Wiring routing incorrect
- Steering stem locknut too tight
- Roller bearing damaged
- Bearing race dented or worn
- Steering stem lubrication inadequate
- Steering stem bent
- Tire air pressure too low

**Handlebar shakes or excessively vibrates:**

- Tire worn
- Swingarm sleeve or needle bearing damaged
- Rim warped, or not balanced
- Front, rear axle runout excessive
- Wheel bearing worn
- Handlebar clamp loose
- Steering stem head nut loose

**Handlebar pulls to one side:**

- Frame bent
- Wheel misalignment
- Swingarm bent or twisted
- Swingarm pivot shaft runout excessive
- Steering maladjusted
- Steering stem bent
- Front fork leg bent
- Right/left front fork oil level uneven

**Shock absorption unsatisfactory:**

- (Too hard)
- Front fork oil excessive
- Front fork oil viscosity too high
- Front fork leg bent
- Tire air pressure too high

Rear shock absorber maladjusted  
(Too soft)  
Front fork oil insufficient and/or leaking  
Front fork oil viscosity too low  
Front fork, rear shock absorber spring weak  
Rear shock absorber gas leaking  
Rear shock absorber maladjusted

**Brakes Don't Hold:**

Air in the brake line  
Pad or disc worn  
Brake fluid leak  
Disc warped  
Contaminated pads  
Brake fluid deteriorated  
Primary or secondary cup damaged  
Master cylinder scratched inside  
Brake maladjustment  
(lever or pedal play excessive)







- If your bike pings or rattles, make sure the gasoline you are using is fresh and of a sufficient octane rating. You might also try different brands of high-octane gasoline.

### Making setting changes

Carb setting changes are made by changing or adjusting four carburetor components.


Four components, the jet needle, main jet and slow jet, regulate the flow of fuel; air screw regulate the flow of air. The following chart indicates the working range of each components. Note how the working ranges overlap each other as the throttle valve moves from closed to fully open.



If you note a particular symptom of rich or lean running in a specific range, use the chart to determine which component needs changing. Use the following information to decide what changed to make.

### Main Jet

The main jet has its greatest effect in the 1/2-to-full-throttle range. The number of the main jet, stamped on the bottom or side of the jet, indicates the relative size of the hole in the jet which meters fuel. The larger the number on the main jet is, the bigger the hole and the more fuel it will pass; hence, larger numbers mean richer jetting. Smaller numbers, of course, mean leaner jetting. Make main jet changes one step at a time.



A. Main Jet

**⚠ WARNING**

Gasoline is extremely flammable and can be explosive under certain conditions. Always stop the engine and do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.


**Jet Needle**

The jet needle and jet needle hole together have their greatest effect in the ¼-to-¾-throttle range. The needle moves in and out of the jet needle hole; since the needle is tapered, its position in the jet determines the amount of

fuel allowed through. There are five grooves in the top of the needle in which a circlip fits. This clip locates the needle in the throttle valve and, therefore, determines its position relative to the jet needle hole.


Moving the clip down has the effect of pulling the needle further out of the jet; the mixture is thereby richened. Moving the clip up leans the mixture. Change the clip position one step at a time.

The straight section of the jet needle affects throttle response at smaller throttle openings.




### Slow Jet and Air Screw

The slow jet and air screw controls the mixture in the closed-to- $\frac{1}{8}$ -throttle range, but has little effect on up to full throttle. To adjust the mixture in this range, the air screw can be turned to change the air flow through the circuit, or the slow jet can be changed to provide more or less fuel. Start by turning the air screw. Screwing it in richens the mixture. Air screw specs indicate the turns out from a lightly seated position. Make changes in  $\frac{1}{2}$  turn increments. If turning the screw between one and two-and-a-half turn's doesn't provide the desired results. The slow jet has a number stamped on it which indicates its size; the larger the number is, the richer the jet. Make one-step changes in the slow jet, and fine-tune with the air screw.



A. Slow Jet



A. Air Screw

### Test Runs

- Warm up the engine with the carburetor at the standard settings, and run two or three laps of the course while examining the operating condition of the spark plug.
- Test-ride the bike by varying the throttle opening.


Condition of spark plug	
Correct	Insulator is dry and light tan color.
Too lean	Insulator is whitish.
Too rich	Insulator is wet and sooty.

- ★ If spark plug is whitish, the fuel-air mixture is too lean.
  - Replace the main jet with one step larger.
- ★ If spark plug is wet, the fuel-air mixture is too rich.
  - Replace the main jet with one step smaller.
  - Set the carburetor so that the engine delivers satisfactory power at any throttle opening.
- ★ If the air-fuel mixture is too lean, the engine tends to overheat and may seize up; on the other hand, if it is too rich, the spark plug easily gets wet, thus causing misfires. The proper strength of the mixture varies depending on atmospheric conditions (pressure, humidity, and temperature). Taking these conditions into consideration, adjust the carburetor settings properly.

**Correction Factors:**  
(For changes in altitude and temperature)

#### **NOTE**

○ *For the following recommendations to be accurate, you must use the standard settings as a base-line. Also, don't change any of the settings until you've determined what changes are necessary. All specifications are based on the use of the specified fuel and oil.*



Jet Needle/Air Screw Chart					
Correction factors	1.06 or above	1.06 – 1.02	1.02 – 0.98	0.98 – 0.94	0.94 or below
Jet needle setting	Lower clip one position	Same			Raise clip one position
Air screw opening	one turn in	½ turn in	Same	½ turn out	One turn out position

## Standard Settings

### KX125:

Air screw opening	1½
Throttle valve cutaway	6.0
Slow jet	42
Jet needle	R1469H/OXHHK
Jet needle clip position	3
Main jet	160

### KX250:

Air screw opening	1½
Throttle valve cutaway	7.0
Slow jet	45
Jet needle	NOZG
Jet needle clip position	3
Main jet	158

(C) : Canadian model

### KX500:

Air screw opening	1½
Throttle valve cutaway	7.0
Slow jet	58
Jet needle	N82M
Jet needle clip position	3
Main jet	168

1. Find your correction factor to adjust the carburetor.  
EXAMPLE: 1000 meters (3200 ft) altitude with an air temperature of 35°C (95°F). The correction factor is 0.94 (see dotted line for the example).
2. Using your correction factor, select the correct slow jet and main jet.  
EXAMPLE: For a correction factor of 0.94, multiply the jet size by that number.

○ Slow jet: (KX125) # 42 x 0.94 = # 40

(KX250) # 45 x 0.94 = # 42

(KX500) # 58 x 0.94 = # 55

○ Main jet: (KX125) # 160 x 0.94 = # 150

(KX250) # 158 x 0.94 = # 148

(KX500) # 168 x 0.94 = # 158

3. Find your correction factor on the Jet Needle/Air Screw chart and change the jet needle clip position and air screw opening as indicated.  
EXAMPLE: For correction factor of 0.94, raise the needle clip one position and turn out the air screw one extra turn.  
○ Jet needle clip setting: 3rd groove from top minus 1 = 2nd groove  
○ Air screw opening: 1½ + 1 turn = 2½ turns out

## Suspension Tuning

### Introduction

No area of machine adjustment is more critical than proper suspension tuning. An improperly tuned suspension will keep even the best rider from attaining the full benefit of his machine's ability. Match the suspension to the rider and the course conditions.

WHILE TUNING THE SUSPENSION, KEEP THE FOLLOWING IMPORTANT POINTS IN MIND:

- If the machine is new, break-in the suspension with at least one hour of riding before making any setting evaluations or changes.
- The three major factors which must be considered in suspension tuning are RIDER WEIGHT, RIDER ABILITY, and TRACK CONDITIONS. Additional influences include the RIDER'S STYLE and POSITIONING on the machine.
- If you have a problem, test by changing your riding posture or position so that the cause of the problem can be deduced.
- It is a wise practice to adjust suspension settings to suit the rider's strong points. If you are fast through the corners, adjust the suspension to allow fast cornering.
- Make setting changes in small increments; a little bit goes a long way, and it is very easy to overadjust a setting.
- The front and rear suspension should be balanced; when one is changed, the other might need to be changed similarly.
- When evaluating suspension performance the rider must make every effort to ride consistently and recog-

nize the effects of his input; such things as changes in rider position and increasing fatigue may lead to incorrect judgments about necessary setting adjustments.

- When the proper settings have been determined for a particular track, they should be written down for reference when returning to that track.
- Lubricate the bearings in the swingarm and uni-trak linkage after break-in and after every 5 races to prevent excess friction from affecting suspension performance.

## Front Fork


### Front Fork Oil Level

The fork oil level in the fork tube is adjustable. A change in the fork oil level will not affect the spring force much at the top of fork travel, but it will have a great effect at the bottom.

- When the oil level is raised:  
The air spring effect becomes more progressive, and the front fork action feels "harder" in the later stage of travel, near the bottom.
- When the oil level is lowered:  
The air spring is less progressive, and the front fork does not become as "hard" in the later stage of travel.



## Suspension Tuning



Changing the fork oil level works effectively at the end of fork travel. If fork bottoming is experienced, raise fork oil level in 10mm (0.4 in) increments. This will change the secondary spring rate.

## Oil Level Adjustment

- Adjust the front fork oil level (see the Oil Level Adjustment of the Front Fork section in the Maintenance and adjustment chapter).

## Troubleshooting Improper Settings:

Listed below are some symptoms of improper suspension settings and the most likely means of correcting them. The proper settings can be achieved by applying the information in this chapter in a scientific, methodical manner; this does not mean, however, that you must be a scientist or trained technician to succeed. Simply take time to think about the changes you believe are necessary, check them against the symptoms and cures described here, make the changes in small increments, and take notes on the changes and their effects.

### *Symptoms of the Front Forks*

#### **Too hard**

1. The front forks are too stiff
  - ..... rebound or compression damping adjustment incorrect.
  - ..... the springs are too strong.
  - ..... too much oil.
  - ..... too heavy oil.
2. The front forks stiffens up the end of stroke
  - ..... the fork oil level is too high.
3. The front forks operate but ride is too hard
  - ..... oil too heavy
  - ..... worn out fork oil

#### **Too soft**

The front forks dive excessively during braking and deceleration.

1. Fork oil level is low.
2. Springs are too soft.
3. Oil too light.
4. Fork oil is worn out.
5. Rebound or compression damping adjustment incorrect.

### *Symptoms of the Rear Shock*

#### **Too hard**

1. The suspension is too stiff
  - ..... compression damping is too high.
  - ..... spring is too hard.
2. The suspension operates but ride is too hard.....unbalance between the spring and rebound damping (rebound damping is too low).
3. Spring preload is too hard.

#### **Too soft**

On landing after a big jump, bottoming occurs (Normally OK)

- ..... spring preload is too soft or compression damping is too soft.
- ..... spring is too soft.
- ..... shock oil is worn.

## *Determining the Proper Settings*

### **Standard Settings**

From the factory, the machine is set up for an intermediate-weight rider possessing intermediate riding ability. Hence, if the actual rider weight considerably more or less than this, or if his riding experience and ability are much greater or lesser than the intermediate level, it is likely that some rough adjustment can be made to put the suspension "in the ballpark."

## *Readjustment of the Suspension*

### **Ground surface**

Smooth	Softer spring
Rough	Harder spring

### **Riding experience**

Beginner	Softer spring with more rebound damping
Experienced	Harder spring

### **Rider's weight**

Heavy	Harder spring
Light	Softer spring

### **Type of course**

Many corners	Lower the front end slightly. [Increase the fork tube height 5mm (0.2 in)]. This quickens steering and turning ability.
Fast course	Raise the front end slightly. [Decrease the front tube height 5mm (0.2 in)]. This slows steering gives greater stability at high speed.
Deep whoops, or sandy ground	Raise the front end slightly to gain stability.

After making such preliminary adjustments, begin the actual on-track testing and evaluation.

### *Remember*

1. Always make changes in small increments.
2. Make sure the rider is consistent in his evaluation of improper suspension performance.
3. A change in the front suspension might require a change in the rear, and vice versa.

### *Front and Rear Compatibility*

Use this procedure to determine if the suspension is balanced reasonably well: Hold the bike upright (retract the side stand). While standing next to the machine, lightly pull on the front brake, place one foot on the footpeg closest to you, and push down hard. If the bike maintains its level attitude as the suspension is compressed, the spring rates are well balanced. Sit astride the bike and take a riding posture. Next check to see that the bike is in a horizontal position. If one end drops noticeably more than the other, the front and rear are not compatible and must be readjusted to achieve a better balance.



This is one of the most effective adjustment procedures but suspension settings will vary depending on the conditions at the track and the rider's preferences.

#### **Front end searching during down hill or during acceleration out of corner:**

Front fork is soft.

- Step 1 – Increase the compression damping or rebound damping.
- Step 2 – Increase the oil level **10 mm (0.4 in)**.
- Step 3 – Use alternate harder spring, or increase spring preload.

**Front end "knives" or oversteers in turns:**  
(Front end tends to turn inward)

Front fork is too soft.

- ⊙Step 1 – Increase the compression damping or rebound damping.
- ⊙Step 2 – Increase the oil level **10 mm (0.4 in)**.

### NOTE

○ *Heavier or expert riders may need the heavy spring.*

**Front end pushes or "washes out" in turns:** (*When a front wheel tends to push outward rather than "bite" in a turn*)

Front fork is too stiff.

- ⊙Step 1 – Decrease the compression damping or rebound damping.
- ⊙Step 2 – Release the air at the fork tubes.
- ⊙Step 3 – Decrease oil level **10 – 15 mm (0.4 – 0.6 in)**.
- ⊙Step 4 – Use softer spring.

### NOTE

○ *A softer spring may be required for lighter or less experienced riders.*

**Front fork doesn't respond to small bumps in sweeping turns:**

Front Fork is too hard.

- ⊙Step 1 – Decrease the compression damping or rebound damping.
- ⊙Step 2 – Decrease oil level **10 mm (0.4 in)**.
- ⊙Step 3 – Use softer duty spring.

**Rear end "kicks" when braking over bumps:**

The shock probably has too little rebound damping.  
..... Increase the rebound damping.

**Rear tire won't "hook up" out of corners:**  
(A lack of traction coming out of turns)

The shock may be too stiff.

- ⊙Step 1 – Decrease the rear shock spring preload.
- ⊙Step 2 – Decrease the compression damping.
- ⊙Step 3 – Use softer spring (In case of a lightweight rider.)

**Brake lands on the front wheel off high speed jumps:**

(This may be due to improper riding posture)

Rebound damping is too soft or spring is too hard.

- ⊙Step 1 – Increase rebound damping.
- ⊙Step 2 – Decrease the shock spring preload.
- ⊙Step 3 – Decrease the compression damping.

**Front and rear of the bike bottom off high-speed jumps:**

(If harsh bottoming occurs once or twice per lap of the race)

Front and rear suspension system are too soft.

- ⊙Step 1 – F/F: Increase oil level **10 mm (0.4 in)**.  
R/S: Increase spring preload. Use harder spring.
- ⊙Step 2 – F/F: Use harder spring.  
R/S: Increase compression damping or use harder spring.

## NOTE

○ *After any adjustment, check front and rear compatibility.*

### Adjustment depending on bottoming condition:

#### (Rear shock)

- Bottom at low speed
- Increase spring preload until maximum preload is achieved.
- Bottom after successive 3 or 4 jumps
- Decrease rebound damping.

## NOTE

○ *The rear shock on this machine may mislead some riders.*

- a. The rear shock bottoms when the spring and damping are overcome by the total weight of the machine and rider (due to full stroke).
- b. A bottoming sensation (even though the machine is not bottoming) may actually be the inability of rider and machine weight to overcome an overly stiff spring or excessive damping.

Observe the rear end off jumps; if it doesn't approach bottoming, try lowering the spring preload and damping.

## Gearing

Selection of the secondary reduction ratio (Sprocket).

### Preconditions

Course condition	Rear Sprocket
● Fast course	Small
● Many curves or hills	Large
● Sandy or soft ground	

- If the straight portion of a course is longer, the secondary reduction ratio should be reduced so that the machine speed can be increased.
- When the course has many corners or uphill or is wet, the secondary reduction ratio should be increased so that gear shifting is possible with smooth acceleration.
- Actually, the speed must be changed depending on the ground condition on the day of race and therefore, be sure to run through the racing circuit prior to a race and set the machine suitable for the entire course.
- If the straight portion of a course on which the machine can be run at maximum speed is longer, the machine should be so set that the maximum machine speed can be developed toward the end of the straight course, but care should be taken not to over-rev the engine.

- It is difficult to set the machine so it is best suited for all portions of the circuit. Therefore, determine which circuit portions will have the greatest effect on lap time. Set the machine for these portions. Confirm your settings by recording lap times after each change. In this way the machine will deliver best performance for the entire circuit.

## **Special Care According to Track Conditions**

1. In dry, dusty conditions (such as volcanic ash or fine powdery dust) special care must be given to keeping the air cleaner element clean.
2. When riding on wet heavy clay the mud adheres to the tires and other parts of the vehicle. The mud can add significantly to the weight of the vehicle and therefore reduce performance. Take care to remove built-up mud from the tires and chassis after each ride, before drying occurs.
3. The engine works hardest in muddy conditions and the radiator can become clogged with mud. Take care not to overheat the engine in these conditions. The engine also works very hard when ridden in deep sand.
4. In muddy or sandy conditions adjust the chain looser than in other conditions as the chain and sprockets will pack with mud/sand and reduce chain slack.
5. Check chain and sprocket wear frequently when riding in mud or sand since wear is increased in these conditions.
6. In dusty conditions as the air cleaner collects dust, the engine runs richer. Therefore it may be advisable to run slightly leaner jetting (main jet) in very dusty conditions.





**Seat**

[KX125, 250]

Low: Height = 89 mm (3.50 in)

High: Height = 102 mm (4.02 in)

[KX500]

Low: Height = 135 mm (5.31 in)

Middle: Height = 140 mm (5.51 in)

High: Height = 165 mm (6.50 in)

**Disc Plate**

Front: No Hole (wet condition use)

Rear: No Hole (wet condition use)

**Wheel (except tire)**

Front Wheel Assembly : 1.60-21

Rear Wheel Assembly : (KX125) 1.85-19  
(KX250, 500) 2.15-19



5. Grease the throttle grip and control cables.

**(5) Suggested spare parts**


- Spare wheels (front and rear)
- Shift pedal and brake pedal
- Brake lever, clutch lever, and holders
- Throttle and clutch cables
- Handlebar
- Front and rear fenders, side covers, and number plate
- Radiator, radiator cover, and hoses
- Throttle grip assembly
- Jets (carburetor)
- Air cleaner element
- Muffler, silencer, and installation parts
- Chain case
- Fork springs (for different settings)
- Rear shock absorber spring (for different settings)
- Assorted gearing, mounting bolts and nuts, and circlips
- Electrical parts set
- Spark plugs
- Clutch assembly or friction plates
- Gasket set
- Assorted tires (various compounds and tread patterns for different conditions)
- Front fork assembly
- Piston and piston rings
- Tie wraps, bolts, nuts, O-rings, washers, snap rings, wire, adhesive tape, vinyl tape (or duct tape), and #400 to #600 emery cloth





**KX500:**

1. Spark Plug
2. Ignition Coil
3. Igniter
4. Engine Stop Button
5. Magneto
6. Pickup Coil
7. Excitor Coil



Color Code	
BK	Black
G	Green
O	Orange
R	Red
W	White
Y	Yellow



**KX125-K5**  
**KX250-K5**  
**KX500-E10**



**KAWASAKI HEAVY INDUSTRIES, LTD.**  
Consumer Products Group

Part No. 99920-1866-01

Printed in Japan